



Operation Manual listen unit equicoach

Button and the screen:



LCD Display:

- (1). Signal strength indicator
- (2). Battery level indicator



- (3). Set channels automatically When receive signal from Manager
- (4). Special function character
- (5). Channel Setting indicator
- (6). The first number of volume channel gain at different state
- (7). The second number of volume channel gain at different state

Operation:

1. **Switch On/Off:**
2. **Change Channel:** When device is switch on, **press the key “ F ”and “ - ” at same time until to show the flickering”CH” to set or change channels**, the display will show Channel number (1-99).

Receiver volume Control: When receiver is on, use “ - ” and “ + ” to adjust volume. At the same time, the display will show (0-12) volume number.

GEBRUIK:

1. **Schakel aan/uit:**
2. **Kanaal veranderen** Als het apparaat aanstaat druk gelijktijd “F” en “-“ in en hou vast tot dat in het display “ch”gaan knipperen. Laat de knoppen los en zet vervolgens met de “-“ of “+” knop het apparaat op het juiste kanaal.
3. **Unit volume:** Als de unit aanstaat met de “+” of “-“ knop volume goed zetten.